



The "WFT OFFSET" is the distance from the centerline of the rim to the centerline of the transducer. The "WFT OFFSET" should be as small as possible to reduce the moment load on the WFT. The WFT and adapters need the drawing for additional clearance required for telemetry WFT systems.

3D models and 2D drawings of the LW-2T-20K are available for download on MSC's website. (michsci.com)