Model CBT-mini

- · Clamps to any shaft 25 mm or larger
- Small Package
- 1 strain gauge bridge channels
- Up to 28 hours of battery life
- Lightweight rugged IP67 housing
- Digital 2.4 GHz RF link for reliable transmission without interference or spikes

Description

The Michigan Scientific Clamping Battery Telemetry (CBT-mini) is a wireless, battery powered, signal transmitter for strain gages that easily mounts to shafts with a minimum diameter of 25mm or larger, making it ideal for shaft mounting and very versatile. The Michigan Scientific Telemetry provides reliable signal transmission without interference or signal spikes. The CBT-mini can conveniently be strapped to any shaft with load rated plastic zip ties, steel banding, or hose clamp. The CBT-mini provides excitation and signal conditioning to the strain gages, then digitally transmits the signals via RF in the 2.4 GHz broadcast frequency range. For higher speed shafts when shaft balancing is required a counter weight can be purchased and should be mounted 180 degrees opposite the CBT-mini. The CBT-mini is a small rugged housing and is designed for hostile environments.

Specifications

	CBT - 540
RF Frequency Range	2.4 GHz
Channel Type	Strain Gauge, Full Bridge, 350 Ω or higher
Channel Count	1
Battery Type	Two CR123a lithium batteries
Continuous Battery Life	28 hours for non-rechargeable. 15 hours for re-chargeable
Weight	145 grams (181 grams with batteries installed)
Gain Type	Fixed gain
Input Type	0.1 to 10 mV/V
Shunt Resistor	Fixed 100 k Ω standard, other shunt resistor values available
Typical Broadcast Distance	3-4 meters, line of sight
Channel Sampling Rate	7 kHz
Signal Output	± 10 Volt Analog
System Resolution	14 Bit
Operating Temperature	-40 °C to +60 °C (battery temperature limit)
Power Requirement	9 to 36 VDC, 4.5 Watts
Total System Delay	<200 µs
RF Channels Available	16

8500 Ance Road Charlevoix, MI 49720 Tel: 231-547-5511 Fax: 231-547-7070 01-7-22 Rev. A

http://www.michsci.com Email: mscinfo@michsci.com

MICHIGAN

SCIENTIFIC corporation 321 East Huron Street Milford, MI 48381 Tel: 248-685-3939 Fax: 248-685-5406



Clamping Battery Telemetry





8500 Ance Road Charlevoix, MI 49720 Tel: 231-547-5511 Fax: 231-547-7070 01-7-22 Rev. A MICHIGANSCIENTIFIChttp://www.michsci.comCorporationEmail: mscinfo@michsci.comCorporation

321 East Huron Street Milford, MI 48381 Tel: 248-685-3939 Fax: 248-685-5406