# Wheel Force Transducer

### Model WT10

- 7,700 lbf · ft (10.5 kN · m) capacity
- Adapts to 12 in and larger wheels
- Environmentally protected
- Rugged stainless steel construction
- Consistent sensitivity among all units
- Configured to minimize magnetic sensitivity



### **Description**

The WT10 Wheel Torque Transducer (WTT) is ideal for measuring wheel torque on passenger cars, SUVs, and light duty trucks. It mounts onto the vehicle using custom designed adapters, which duplicate the critical dimensions of the production wheel and place the tires on the production centerline. The LW65 can share the same adapters. Being rugged and waterproof, they are capable of on-road and off-road measurements in all conditions.

The WT10 measures all torque developed between the tire patch and the vehicle hub and can be used for drivetrain development to study efficiency, optimize component design, and monitor torque distribution in all-wheel-drive vehicles. It is also ideal for brake system component development, as well as anti-lock brake development, traction control, and vehicle stability system design. Measured data can be used for component development, computer modeling and laboratory simulation and validation.

# **Specifications**

Full Scale Measurable Load	7,700 lbf · ft (10.5 kN · m)
Max. Torque Capacity	7,700 lbf · ft (10.5 kN · m)
Maximum Static Weight (Fz)	2,900 lb (1,320 kg)
Rim Size	≥ 12 in
Sensor	4 arm strain gauge bridge
Nonlinearity	≤ 0.1 % of full scale output
Hysteresis	≤ 0.15 % of full scale output
Temperature Range, Operating	-40 °F to 350 °F (-40°C to 177 °C)
Excitation Voltage, Maximum	10 Vdc or ac rms
IP Rating	IP67

8500 Ance Road Charlevoix, MI 49720 Tel: 231-547-5511 Fax: 231-547-7070 09-26-22 Rev. A


SCIENTIFIC corporation

http://www.michsci.com Email: mscinfo@michsci.com

321 East Huron Street Milford, MI 48381 Tel: 248-685-3939 Fax: 248-685-5406

## Wheel Force Transducer

### **WT10 Configuration**



#### 1. RIM ADAPTER

Modified production wheel or custom machined wheel for mounting transducer to wheel

#### HUB ADAPTER

Custom adapter that mounts transducer and rim adapter assembly to production vehicle hub

### 3. QUICK CONNECT LUG NUT COLLETS

Quick Connect Lug Nut Collets mount to standard lug nuts

#### 4. STATOR RESTRAINING ROD

Stabilizes the stator of the slip ring assembly relative to the vehicle for angle reference

#### WHEEL TORQUE TRANSDUCER

Measures drive and braking torque at vehicle corner

#### SIGNAL CONDITIONING

#### 6. Wheel Instrumentation Package (WIP)

Mounts to a variety of wheel lug bolt patterns and conditions signals from the transducer and provides (optional) thermocouple signal conditioning

### 7. Slip Ring Assembly

Measures rotational velocity and angular position while completing electrical connection between rotational and stationary components

#### OR

#### 8. Telemetry Data Transmission Electronics

Wireless signal transfer to receivers located inside vehicle Does not provide rotational velocity or angular position

# Ordering Options

Michigan Scientific offers a fully weatherproof slip ring, encoder, and amplifier instrumentation assembly to be used with all Wheel Torque Transducers. Refer to the Instrumentation Assemblies section for more information.

8500 Ance Road Charlevoix, MI 49720 Tel: 231-547-5511 Fax: 231-547-7070 09-26-22 Rev. A

SCIENTIFIC corporation

http://www.michsci.com Email: mscinfo@michsci.com

321 East Huron Street Milford, MI 48381 Tel: 248-685-3939 Fax: 248-685-5406