

# Wheel Force Transducer

## Model WT20

- 14,750 lb · ft (20 kN · m) capacity
- Adapts to 16 in and larger single or dual wheels
- Environmentally protected
- Rugged stainless steel construction
- Consistent sensitivity among all units
- Configured to minimize magnetic sensitivity



## Description

The *WT20 Wheel Force Transducer (WFT)* is capable of measuring all of the wheel forces and moments on light and heavy duty pickup trucks vans and SUVs. One transducer will measure the combined torque load for a dual-wheel set or a single tire. It mounts onto the vehicle using custom designed adapters, which duplicate the critical dimensions of the production wheel and place the tires on the production centerline. The *LW-2T-20K* can share the same adapters. Being rugged and waterproof, they are capable of on-road and off-road measurements in all conditions.

The *WT20* measures all torque developed between the tire patch and the vehicle hub and can be used for drivetrain development to study efficiency, optimize component design, and monitor torque distribution in all-wheel-drive vehicles. It is also ideal for brake system component development, as well as anti-lock brake development, traction control, and vehicle stability system design. Measured data can be used for component development, computer modeling and laboratory simulation and validation.

## Specifications

Full Scale Measurable Load	14,750 lbf · ft (20 kN · m)
Max. Torque Capacity	14,750 lbf · ft (20 kN · m)
Maximum Static Weight (Fz)	4,000 lb (1,800 kg)
Rim Size	≥ 16 in
Sesnor	4 arm strain gauge bridge
Nonlinearity	0.1 % of full scale output
Hysteresis	0.05 % of full scale output
Temperature Range, Operating	-40 °F to 350 °F (-40°C to 177 °C)
Excitation Voltage, Maximum	10 Vdc or ac rms
IP Rating	IP67

8500 Ance Road  
Charlevoix, MI 49720  
Tel: 231-547-5511  
Fax: 231-547-7070  
03-9-22  
Rev. A

**MICHIGAN SCIENTIFIC**  
corporation  
<http://www.michsci.com>  
Email: [msscinfo@michsci.com](mailto:msscinfo@michsci.com)

321 East Huron Street  
Milford, MI 48381  
Tel: 248-685-3939  
Fax: 248-685-5406

# Wheel Force Transducer

---

## WT20 Configuration

### Ordering Options

Michigan Scientific offers a fully weatherproof slip ring, encoder, and amplifier instrumentation assembly to be used with all Wheel Torque Transducers. Refer to the Instrumentation Assemblies section for more information.

8500 Ance Road  
Charlevoix, MI 49720  
Tel: 231-547-5511  
Fax: 231-547-7070  
03-9-22  
Rev. A

**MICHIGAN SCIENTIFIC**  

---

**corporation**  
<http://www.michsci.com>  
Email: [mscinfo@michsci.com](mailto:mscinfo@michsci.com)

321 East Huron Street  
Milford, MI 48381  
Tel: 248-685-3939  
Fax: 248-685-5406